


# Neoclassical Pulses


# Basic Stuff: main terms

Left Hand




# Basic Stuff: other terms

Left Hand



# Basic Stuff

**Left Hand = Xue Side**




**HT**

**LV**

**KI (Yin - Xue)**

**Right Hand = Qi Side**



**SP**

**LU**

**KI (Yang - Qi)**

# Summary of Basic Stuff

Position				Left	Right
1 <sup>st</sup> Distal	Cun	Inch	Inch	HT/SI	LU/LI
2 <sup>nd</sup>	Guan	Gate	Bar	LV/GB	SP/ST
3 <sup>rd</sup> Proximal	Chi	Foot	Cubit	KI/BL	KI/SJ

# 6 Channel Pulses


- Yang Ming = LI & ST
  - Tai Yang = SI & BL
- Shao Yang = SJ & GB
  - Tai Yin = LU & SP
- Shao Yin = HT & KI
  - Jue Yin = PC & LV

# 6 Channel Pulses


One of the six channel pulses is felt to either the radial or ulnar side of the vessel, when the wei qi flows outside of the vessel:

Yang pulses on the radial side.

Yin pulses on the ulnar side.




# 8 Extraordinary Vessel Pulses



**Du Pulse** = All three  
pulses even, level  
and superficial  
Master Point = SI-3




# 8 Extraordinary Vessel Pulses



**Ren Pulse** = All three  
pulses even, level  
and at moderate  
depth


**Master Point = LU-7**

# 8 Extraordinary Vessel Pulses




**Chong Pulse** = All three  
pulses even, level and  
at full depth  
Master Point = SP-4

# 8 Extraordinary Vessel Pulses




**Yang Qiao Pulse =**  
Distal pulse is larger,  
hits the fore finger first  
Master Point = BL-62

# 8 Extraordinary Vessel Pulses




**Dai Pulse** = Middle  
pulse is larger, hits the  
middle finger first  
Master Point = GB-41

# 8 Extraordinary Vessel Pulses




**Yin Qiao Pulse =**  
Proximal pulse is larger,  
hits the ring finger first  
Master Point = KI-6

# 8 Extraordinary Vessel Pulses




**Yang Wei Pulse** = All three pulses even, level but the distal pulse is radial and the proximal pulse is more ulnar in location  
Master Point = SJ-5

# 8 Extraordinary Vessel Pulses



**Yin Wei Pulse** = All three pulses even, level but the distal pulse is ulnar and the proximal pulse is more radial in location  
Master Point = PC-6



Cycle begins at 3:00 a.m. in LU and moves in 2-hourly intervals, ending in LV




# Ying Qi Cycle


1. Ying qi is the nutritive qi cycle and moves from organ to organ in two-hour intervals (see previous slide).
2. Compare relative size of two pulses in the cycle.
3. A large pulse in the first position of the cycle pair, followed by a comparatively small pulse at the next location in the cycle indicates a blockage in the channel pertaining to the large pulse and therefore a restriction in downstream flow.
4. Use the entry & exit points on each channel to stimulate flow and then see if the pulses level out.
5. Reduce the upstream exit point and tonify the downstream entry point.

# Ying Qi: LI > ST

Left Hand




Right Hand



# Ying Qi: SI > BL

Left Hand




Right Hand




# Ying Qi: SJ > GB

Left Hand




- SJ-22,  
+ GB-1

Right Hand




# Ying Qi: LV > LU

Left Hand




- LV-14,  
+ LU-1

Right Hand




# Ying Qi: SP > HT

Left Hand




- SP-21,  
+ HT-1

Right Hand




# Ying Qi: KI > PC

Left Hand



- KI-22,  
+ PC-1

Right Hand




# Wei Qi Cycle

1. Wei qi is the defensive qi cycle, moves from organ to organ in twenty-eight-minute intervals and compliments the ying qi cycle.
2. Compare relative size of two pulses in the cycle.
3. A large pulse in the first position of the cycle pair, followed by a comparatively small pulse at the next location in the cycle indicates a blockage in the channel pertaining to the large pulse and therefore a restriction in downstream flow.
4. Use the correct compass point (next slide) on the large pulse channel to stimulate flow and then see if the pulses level out.
5. Also use the back shu and/or front mu points of the affected channels.



# Compass Method




Using the large pulse position of any wei qi pair, roll the finger around the pulse location and feel where it is largest. Go to the element shown by the compass on the pulse channel to effect a change in the Wei Qi flow. The compass method can be used to resolve imbalance at any location.

# Wei Qi: KI > HT

Left Hand




Right Hand





# Wei Qi: HT > LU

Left Hand




Right Hand




# Wei Qi: LU > LV

Left Hand




Right Hand




# Wei Qi: LV > SP

Left Hand




Right Hand



# Wei Qi: SP > KI

Left Hand



Right Hand

